



METHOD STATEMENT

1. Mark location of entry point and angle of fixing on timber.
2. If required pre-drill using a pilot drill of specified size to aid penetration.
3. Fast Flex fixings are to be driven using a power support tool in an SDS+ hammer drill.
4. Number of fixings per joint and minimum penetration into timber will depend upon the loading required
5. Make good at surface of all holes and leave ready for any decoration.

Notes : Unless specified otherwise the following criteria are to be used.

- a. 8mm Fast Flex fixings are to be used.
- b. A 5 or 6mm pilot drill is to be used in hard timber.
- c. Where a specific loading is required a test unit can be used to measure the pull outs achievable at various depths of penetration.